# MITEL 5320 IP PHONE



- Display
- Ring/Message Indicator
- Volume, Speaker and Mute Controls
- Fixed Function Keys
- Dial Pad
- Navigation Page Keys
- Programmable Feature Keys and Softkeys Transfer/Conference
- Speaker
- Handset



Speaker



Mute



Menu



Cancel



Redial







Message

# Mitel Mitel

NOTE: For more information about using other features and applications on your 5320 IP Phone, refer to 5320 IP Phone User Guide located at www.mitel.com, or contact your Administrator. SIP Users: Refer to the 5320/5330/5340 SIP User and Administrator Guide.

#### Make a Call

- Lift the handset OR
- Press (1)
- **5** Dial the number OR
- Press a Speed Call key OR
- 4 Press 123 OR
- **5** Dial the prefix for external calls (e.g. 9) and the number.

#### Answer a Call

- Lift the handset OR
- 3 Press (1), and begin speaking.

#### End a Call

- 4 Press (X) OR
- Replace the handset.

#### Place a Call on Hold

- 4 Press . The line key flashes.
- **9** Replace the handset if necessary.

#### Retrieve a Call from Hold

- **9** Lift the handset OR
- 3 Press (1).
- Press the flashing line key.

## Retrieve a Message

- 4 Press It flashes when a message is
  - Follow the voice mail prompts to retrieve your message.

#### Transfer a Call

- 4 Press ASS.
- **5** Dial the number. Wait for an answer.
- Hang up OR announce the transfer and then hang up.

#### Conference a Call

- 4 Press A St.
- 5 Dial the number. Wait for an answer.
- 4 Press A St.

### Program a Speed Call

4 Press Menu OR

Press Settings.

Press Programmable Keys.

Press the key you wish to program.

Press Speed Call.

Press Edit Info and enter the label for the Speed Call.

Press Save.

Press Edit Number and enter the phone number for the Speed Call.

Press Save, and then press Save again. Press Close and then press Close again.

## Adjust Volume Levels

Adjust ringer volume while the phone is ringing. Adjust handset or speaker volume while using the handset or speaker.

- 3 Press repeatedly to raise the volume OR
  - repeatedly to lower the volume.
- 3 Press **b** to mute your microphone.